

# Montageanleitung Transportwagen „Cargo Box“

## Assembly instruction trolley „Cargo Box“

- 12 x DIN603 M6x70
- 12 x DIN985 M6
- 12 x DIN125 D6
- 12 x DIN603 M8x60
- 30 x DIN985 M8
- 6 x DIN125 D8
- 18 x DIN7991 M8x30

6 x DIN603 M6x70



6 x DIN603 M6x70



6 x DIN985 M6  
6 x DIN125 D6



6 x DIN985 M6  
6 x DIN125 D6



3 x DIN603 M8x60



2 x DIN603 M8x60



6 x DIN7991 M8x30



4 x DIN603 M8x60



3 x DIN603 M8x60



3 x DIN985 M8  
3 x DIN125 D8



24 x DIN985 M8  
Keine U-Scheibe bei Räderbefestigung!  
*No U-washer for wheels attachment!*



12 x DIN7991 M8x30



3 x DIN985 M8  
3 x DIN125 D8


