

Montageanleitung Transportwagen „Cargo Box“
Assembly instruction trolley „Cargo Box“



TOP Quality
made in
GERMANY

Montageanleitung Transportwagen „Cargo Box“

Assembly instruction trolley „Cargo Box“

- 12 x DIN603 M6x70
- 12 x DIN985 M6
- 12 x DIN125 D6
- 12 x DIN603 M8x60
- 30 x DIN985 M8
- 6 x DIN125 D8
- 18 x DIN7991 M8x30

